



展开：560X210mm-折好140X210mm

Once it has been filtered, discard the water or use it to water plants. Fill with water again and discard. Fill the reservoir a third time and pour the water for drinking.

NOTE: It is normal for carbon dust to appear in the first two pitchers. Always allow all the water in the Reservoir to pass through the filter before pouring the water.



2 x 3=OK



7. Set the Filter Life Indicator:
Press and hold the Start button for a few seconds until the timer shows "35" days, change the filter when the timer reach "00".

Press Filter Change Indicator button for more than 5 seconds until the display shows "00" to be blinking, press it again, the timer will display the usable life of cartridges (in days).

For best results:

- Keep enough water in the pitcher to maintain the bottom of the filter in the water. This will prevent the filter from drying out. If the filter has not been in contact with water for two days, re-soak it for 10 minutes and then reinstall it.
- Store the pitcher in the refrigerator or in a cool location. If the water has been sitting for several days, discard it and refill the pitcher with fresh water.


Replacing the Filter
Replace the Filter when the time indicator displays "00". Pull it out of the Pitcher by its Loop. Repeat steps 4-7 to install a new Filter.

NOTE: NAMI-FILTROS® filters also fit this Pitcher.

whatshome®

**WATER FILTER PITCHER
NAMI-JARRA**

Use and Safety Instructions



CONTENT 4 PIECES:
-1 PITCHER
-1 LID
-1 RESERVOIR
-1 FILTER CARTRIDGE

READ ALL INSTRUCTIONS BEFORE USE

READ ALL INSTRUCTIONS BEFORE USE

The water filtration system reduces chloride and particles in tap water and improves the taste, smell, and clarity of it. It also provides a more economical and environmentally friendly alternative to buying bottled water.

Save money and enjoy the fresh, crisp taste of water.

WARNING


- This product is intended to filter tap water only. Do not put water of unknown quality or that has been micro-biologically impaired into the product.
- If official instructions have been issued to boil tap water before consuming it, the water placed into this product must also be boiled, either before or after passing through the Filter.
- If persons with weak immune systems, such as babies or the elderly, have been advised to boil tap water before consuming it, the water placed into this product for consumption by these persons must also be boiled, prior to or after filtration.

CAUTION

- Place only cold or room temperature water into the product for filtering.
- Do not apply concentrated cleaning agents such as heavy oxidants, bleach, chlorinated solvents, or the like to any part of the product. Do not use abrasive pads on the product.
- This product is not fit for the dishwasher.
- If the pitcher or reservoir is broken or cracked, replace the whole product. If the filter is damaged, replace only the filter.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE


PARTS




Filter Life Indicator
Lid
Loop of Filter Cartridge
Filter Cartridge
Reservoir
Pitcher

TO SET UP AND USE


- Remove the lid by pulling up on both sides of it.
- Hand wash the pitcher, reservoir, and lid with a soft cloth or sponge and a mild liquid soap. Rinse and let dry.
- Place the reservoir back into the pitcher as shown in the diagram; the tallest part of the reservoir must face the front of the pitcher.



- Prepare and install the filter:
*Use cold or room temperature water.
 - Wash your hands and then remove the filter from its package. Soak it upright in water for 10 minutes.
 - Rinse the filter under running water for 10 seconds.
 - Press it firmly down into the tube of the reservoir to ensure a tight seal.




- Attach the lid.




- Fill the pitcher:
*Always use cold or room temperature water when filling the pitcher. Press down on the tab next to the filter life indicator to open the hole in the lid. Fill the reservoir with water.

Desheche las dos primeras cargas de agua. El tercer llenado es apto para beber.

NOTA: Es normal que aparezca polvo de carbón en las dos primeras cargas. Siempre deje que toda el agua del depósito pase por el filtro antes de servir.



2 x 3=OK



7. Configurar el indicador de vida del filtro:
Mantenga presionado el botón "Start" hasta que muestre "60" días. Cambie el filtro cuando llegue a "00".

Presione el botón Indicador de cambio de filtro durante más de 5 segundos hasta que la pantalla muestre "00" parpadeando, presiónelo nuevamente, el temporizador mostrará la vida útil de los cartuchos (en días).

Para mejores resultados:

- Mantenga suficiente agua en la jarra para que el filtro no se seque. Si el filtro no ha estado en contacto con agua por 2 días, remójelo nuevamente 10 minutos antes de usar.
- Guarde en refrigerador o en un lugar fresco. Si el agua lleva varios días, deséchela y llene con agua fresca.


Reemplazo del filtro:
Reemplace el filtro cuando el indicador marque "00". Retírelo sujetando el asa y repita los pasos de instalación.

AVISO: Adquiera el modelo NAMI-FILTROS® para reemplazar el cartucho de filtro.

whatshome®

**JARRA CON FILTRO PARA AGUA
NAMI-JARRA**

Instrucciones de uso y seguridad



CONTIENE 4 PIEZAS:
-1 JARRA
-1 TAPA
-1 DEPÓSITO
-1 CARTUCHO DE FILTRO

LEA TODAS LAS INSTRUCCIONES ANTES DE USAR

LEA TODAS LAS INSTRUCCIONES ANTES DE USAR

El sistema de filtración de agua reduce el cloro y las partículas presentes en el agua de la llave, mejorando su sabor, olor y claridad. También ofrece una alternativa más económica y ecológica a la compra de agua embotellada. Ahorre dinero y disfrute del sabor fresco y puro del agua.

ADVERTENCIA


- Este producto está diseñado únicamente para filtrar agua de la llave o embotellada. No introduzca agua de calidad desconocida o que haya sido comprometida microbiológicamente.
- Si las autoridades han indicado hervir el agua antes de consumirla, el agua colocada en este producto también debe hervirse, antes o después de pasar por el filtro.
- Si personas con sistemas inmunológicos débiles, como bebés o adultos mayores, han sido aconsejadas a hervir el agua antes de consumirla, el agua colocada en este producto para su consumo también debe hervirse, antes o después de la filtración.

PRECAUCIÓN

- Use únicamente agua fría o a temperatura ambiente para filtrar.
- No use agentes de limpieza concentrados como oxidantes fuertes, cloro, solventes clorados o similares en ninguna parte de este producto. No use fibras o estropajos abrasivos.
- Este producto no es apto para lavavajillas.
- Si la jarra o el depósito están rotos o agrietados, reemplace todo el producto. Si el filtro está dañado, solo reemplace el filtro.

GUARDE ESTAS INSTRUCCIONES PARA REFERENCIA FUTURA


PARTES




Indicador de vida del filtro
Tapa
Asa del cartucho de filtro
Cartucho de filtro
Depósito
Jarra

PARA CONFIGURAR Y USAR


- Retire la tapa levantando ambos lados.
- Lave a mano la jarra, el depósito y la tapa con un paño suave o esponja y jabón líquido suave. Enjuague y deje secar.
- Coloque el depósito en la jarra con la parte más alta hacia el frente.



- Preparar e instalar el filtro:
* Use agua fría o a temperatura ambiente.
 - Lave sus manos y saque el filtro del empaque.
 - Remójelo en posición vertical en agua durante 10 minutos.
 - Enjuáguelo bajo el chorro de agua durante 10 segundos.
 - Insértelo firmemente en el tubo del depósito hasta que selle.



- Colocar la tapa.



- Llene la jarra:
* Siempre use agua fría o a temperatura ambiente. Presione la pestaña junto al indicador de vida del filtro para abrir el orificio en la tapa. Llène el depósito y deje filtrar todo el agua.